

## **Technical Data Sheet**

Issued in: 01/2022

Revised in: 05/2022

# **ONEBOND ONE CLEANER**

#### **Description**

OneBond One Cleaner is a multi-purpose, water-based active foam cleaning agent, remove dirt without leaving marks. Effectively removes contaminants from surfaces. Excellent for cleaning before application of OneBond adhesives and sealants in the automotive glass replacement aftermarket and any other full cleaning process in the industrial works.

#### **Technical Data**

Appearance	Foaming aerosol
Colour:	White
Chemical nature:	Water based detergente
Odour:	Perfume
Application:	Sponge, pape ror cloth
Application temperature (°C)	From +0 to +40

### **Application**

Ensure thorough cleaning of the substrate. Apply OneBond One Cleaner and pass over with mildly abrasive sponge and/or a lint free adsorbent cloth, removing contaminants and excess foam while drying the surface. Shake can before application. Complete the full adhesion process within hours to avoid dust and other material to contaminate again the surfaces. If used to clean sensible surfaces like skin upholstery in car seat, test the product in a non-visible area.

## **Packaging**

Pressurized spray can 400 ml – 12 pieces per box

#### **Storage**

OneBond One Cleaner can be stored for 12 months in its original packing at 5° - 25°C. Keep out of the reach of children.



# **Technical Data Sheet**

Issued in: 01/2022

Revised in: 05/2022

# **ONEBOND ONE CLEANER**

### **Safety Considerations**

Safety Data Sheets (SDS) are available from OneBond. SDS include information regarding the physical, health, and environmental health hazards, safety precautions, for products handling, storing and disposal. SDS are available in the language of the country or area of destination and may include locally applicable health and safety regulations. SDS are updated regularly and can be downloaded from www.onebondadhesives.com. OneBond encourages users to review the up-to-date SDS before handling or using any product.

#### **Customer Notice**

The data contained here, obtained in OneBond laboratories, are given for information only; if specifics are required, please contact OneBond Technical Department. OneBond ensures abiding quality of supplied products according to its own specifics. OneBond cannot assume responsibility for the results obtained by others which methods are not under OneBond control. It is user's responsibility to determine suitability for user's purpose of any product mentioned herein. OneBond disclaims all warranties expressed or implied, including warranties of merchantability or fitness for a particular purpose, arising from sale or use of OneBond products. OneBond specifically disclaims any liability for consequential or incidental damages of any kind, including lost profits.